










UEBEX
LED LIGHTING

Name

Flutlichtstrahler ATUR2
200W | FLA2200; 400W | FLA2400
600W | FLA2600; 800W | FLA2800

Input Characteristics

200-240V 50/60Hz



No.	Name	No.	Name
1	electric box	6	module connector plate
2	strengthen bracket	7	module angle scale
3	bracket junction plate	8	lamp dial
4	U-bracket	9	adjustable connector
5	butterfly nut	10	light source module



To avoid the risk of fire, explosion, or electric shock, this product should be installed, inspected, and maintained by a qualified electrician only, in accordance with all applicable electrical codes.

To avoid electric shock:

- Be certain electrical power is OFF before and during installation and maintenance.
- Luminaire must be connected to a wiring system with an equipment-grounding conductor.
- Make sure the supply voltage is the same as the rated luminaire voltage.
- Do not operate in ambient temperatures above those indicated on the luminaire nameplate.

To avoid Fire:

- Keep flammable and combustible materials away from the light source and/or lens.
- Ensure lamps are installed correctly.
- Use correctly rated supply conductors as indicated by product labeling.

Burn:

- Allow luminaire and lamps to cool before handling luminaire or changing lamp.
- Follow all warnings, restrictions and recommendations given by the lamp manufacturers.

Personal Injury:

- Wear safety glasses and gloves when handling the luminaire to avoid physical injury.
- Avoid direct eye contact with light source.
- Always support the weight of the luminaire.

