





| | | |
|---|---|-----------------------|
|  | Name | Input Characteristics |
| | Flutlichtstrahler ATUR2 45W I FLA2045 90W I FLA2090 | 120-240V 50/60Hz |





| No. | Name | No. | Name |
|-----|----------------|-----|---------------------|
| 1 | U-bracket | 4 | Lamp Dial |
| 2 | LED Driver | 5 | Light Source Module |
| 3 | Module Bracket | 6 | Electric Box |



To avoid the risk of fire, explosion, or electric shock, this product should be installed, inspected, and maintained by a qualified electrician only, in accordance with all applicable electrical codes.

- To avoid electric shock:**
- Be certain electrical power is OFF before and during installation and maintenance.
 - Luminaire must be connected to a wiring system with an equipment-grounding conductor.
 - Make sure the supply voltage is the same as the rated luminaire voltage.
 - Do not operate in ambient temperatures above those indicated on the luminaire nameplate.

- To avoid Fire:**
- Keep flammable and combustible materials away from the light source and/or lens.
 - Ensure lamps are installed correctly.
 - Use correctly rated supply conductors as indicated by product labeling.

- Burn:**
- Allow luminaire and lamps to cool before handling luminaire or changing lamp.
 - Follow all warnings, restrictions and recommendations given by the lamp manufacturers.

- Personal Injury:**
- Wear safety glasses and gloves when handling the luminaire to avoid physical injury.
 - Avoid direct eye contact with light source.
 - Always support the weight of the luminaire.

